


AMPS EVALH1 Interface Training Board



www.TechnologicalArts.com



Order Codes:
 #EVALH1MIN-x (no options, no LCDs, no keypad)
 * note: keypad and cables for all connectors NOT included
 X replace "x" in order code with desired connector option code

Accessories:
 Keypad, 4x4: #MK4X4
 Keypad, 3x4: #MK3X4
 LCD, 16x4, non-backlit: #LCD16X4
 LCD, 20x4, LED-backlit: #LCD20X4-LB
 XBee ZigBee radio module with chip antenna: #XB24-Z7CIT-004
 USB-to-Xbee host adapter: #USB2X
 USB-to-MCU interface adapter: #USB2MCU

*NOTE: When SCIs are used, the corresponding RXD pin (i.e. RXD0 or RXD1) must be isolated from the RS232 driver chip on the MCU card by removing the related jumper wire on the MCU card. See schematics for details.