




Adapt9S12Cxx Example Configurations




Example A
Fully-populated backplane with one Adapt9S12C module, and custom apps on three prototyping cards




Example C
Plug any -RA or -M module into solderless breadboard, using this adapter




Example B
Remote expansion via ribbon cable




Example E
AD11BP2-SB plugs 2 boards into a solderless breadboard at once




Example D
Planar arrangement




Example F
Add a prototyping card or application card to an -RA module



Example G
Low-cost stacking configuration adds a prototyping card or application card to an -M module



Example H
Add a prototyping card or application card to an -SB module



Example I
Use a MicroCore-11 motor driver board with Adapt9S12C by means of a Bridgeplane adapter