



Adapt11 Modular Prototyping System


Example Configurations




Example A
Fully-populated backplane with one
Adapt11 module, a memory expansion
card, and two prototyping cards




Example C
Plug any -RA or -M module
into solderless breadboard,
using this adapter




Example D
Planar arrangement




Example E
Plug two boards into
solderless breadboard at once




Example F
Add a prototyping card or
application card to an -RA module



Example G
Low-cost stacking configuration
adds a prototyping card or
application card to an -M module



Example H
Add a prototyping card or
application card to an -SB module



Example I
Use a MicroCore-11 motor driver
board with Adapt11 by means of a
Bridgeplane adapter